



Important information on your Digit MF4-T!

Dear Customer,

the remote control included in this delivery is, after insertion of the batteries, set to the remote option **Sat 1**. But since the receiver uses in the factory setting the remote option **Sat 2**, it is **absolutely** necessary to change the remote option after insertion of the batteries. For this purpose, please follow the following steps:

- > To change the remote option, please push the buttons **SAT2** and **OK** at the same time!!! Now, the receiver can be operated with this remote control without any restrictions.

The change of the remote option possibly might also be necessary again after a battery change.

Further information on the remote option and its change in device and remote control you will find in the instruction manual under **point 2** and **6.2.3**.



OK

Sat 2

Your

TechniSat-Team



Important information on your Digit MF4-T!

Dear Customer,

the remote control included in this delivery is, after insertion of the batteries, set to the remote option **Sat 1**. But since the receiver uses in the factory setting the remote option **Sat 2**, it is **absolutely** necessary to change the remote option after insertion of the batteries. For this purpose, please follow the following steps:

- > To change the remote option, please push the buttons **SAT2** and **OK** at the same time!!! Now, the receiver can be operated with this remote control without any restrictions.

The change of the remote option possibly might also be necessary again after a battery change.

Further information on the remote option and its change in device and remote control you will find in the instruction manual under **point 2** and **6.2.3**.



OK

Sat 2

Your

TechniSat-Team